

Service Manual

Microwave Oven

NN-V359WB



Specifications:

Power Source:	240 V AC Single Phase, 50 Hz
Power Requirements:	Microwave: 1100W, Grill: 1210W, Maximum: 1890W
Output: (IEC705-88)	900W
Microwave Frequency:	2,450Mhz
Timer:	99 min. 99 sec.
Oven Cavity Size:	20L
Outside Dimensions:	458mm (W) X 315mm (D) X 299mm (H)
Inside Dimensions:	315mm (W) X 298mm (D) X 208mm (H)
Weight:	12 Kg
Inverter Power Supply	
Output power:	IEC705-88 Test procedure
Specifications subject to change without notice	

Panasonic®

© 1999 Matsushita Electric Industrial Co., Ltd.
All rights reserved. Unauthorized copying and
distribution is a violation of law.

WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product dealt with in this service information by anyone else could result in serious injury or death.

WARNING

* This product should be serviced only by trained, qualified personnel.

This service manual covers products for following markets.

When troubleshooting or replacing parts, please refer to the country identifications shown below for your applicable product specification.

BPQ ... for the United Kingdom

DANGER OF HIGH VOLTAGE AND HIGH TEMPERATURE (HOT/LIVE) OF THE INVERTER POWER SUPPLY(U)

INVERTER WARNING **NEW H.V.**

This Inverter board looks like a regular PCB, however, this PCB drives the magnetron tube with extremely high voltage and high current.

IT HAS: 1: Very high voltage and high current circuit.

It functions the same as the high voltage transformer and high voltage capacitor in ordinary microwave ovens.

2. aluminium heat sink is very hot in high voltages and heat energy.

3. Very high voltage may remain in the circuitry even when the oven is off. High voltages may remain in the capacitors on the board.

DO NOT: *1. Do not touch the circuitry as it becomes very hot (high voltage). Even when replacing board, extreme care should be taken to avoid possible electric shock hazards. High voltage may remain in the circuit.

*2. Do not touch aluminium heat sink because it is very hot in high voltage and also very hot in high heat energy.

*3. Do not try to repair the Inverter PCB as this can be very dangerous. Replace the whole High Voltage Inverter Circuit(U) unit and return fully re-packed with the original shopping box and shipping materials.

*4. Do not try to adjust or tamper with the preset volume on the Inverter board because it is very dangerous to adjust it without proper test equipment.

*5. Do not test oven while Inverter grounding strip or screws are loose. It is very dangerous to operate the H.V. Inverter Circuit (U) with loose mounting screws or if improperly grounded.

INVERTER POWER SUPPLY DIAGRAM




TABLE OF CONTENTS


1. CONTROL PANELS.....	4
2. OPERATION AND DIGITAL PROGRAMMER CIRCUIT TEST PROCEDURE	5
3. SCHEMATIC DIAGRAM.....	8
4. DESCRIPTION OF OPERATING SEQUENCE	9
4.1 Variable power cooking control	9
4.2 Grill cooking	9
4.3 Combination cooking.....	9
4.4 Autoweight defrost, autoweight cook	9
5. CAUTIONS TO BE OBSERVED WHEN TROUBLESHOOTING.....	10
5.1 Check the grounding	10
5.2 Inverter Warnings	10
5.3 When parts must be replaced, remove the power plug from the outlet.....	11
5.4 When the 10A fuse is blown due to the operation of short switch:.....	11
5.5 Avoid inserting nails, wire, etc. through any holes in the unit during operation.....	11
5.6 Confirm after repair	11
5.7 Sharp edges.....	11
6. DISASSEMBLY AND PARTS REPLACEMENT PROCEDURE	12
6.1 Magnetron	12
6.2 Inverter Power Supply(U)	12
6.3 Digital Programmer Circuit (DPC) and membrane key board	13
6.4 Low voltage transformer and/or power relays (RY1).....	13
6.5 Fan Motor.....	13
6.6 Temp sensor (thermal protector).....	13
6.7 Door disassembly.....	14
6.8 Turntable motor	14
6.9 Quartz heater	14
7. COMPONENT TEST PROCEDURE.....	15
7.1 Primary Latch Switch, Secondary (Secondary Latch Switch and Power Relay B) Interlocks.	15
7.2 Short Switch & Monitor Circuit	15
7.3 Magnetron	15
7.4 Push button key board	15
7.5 Inverter Power Supply (U).....	16
7.6 Inverter Power supply(U)	16
7.7 Temp sensor (Thermal protector)	16
8. MEASUREMENTS AND ADJUSTMENTS.....	17
8.1 Installation of Primary latch switch, Secondary latch switch and Short switch.....	17
8.2 Measurement of microwave output.....	17
9. TROUBLESHOOTING GUIDE	18
10. EXPLODED VIEW AND PARTS LIST	22
11. PARTS LISTS	23
12. DOOR ASSEMBLY	24
13. ESCUTCHEON BASE ASSEMBLY	25
14. PACKING AND ACCESSORIES.....	26
15. DIGITAL PROGRAMMER CIRCUIT	28
16. DIGITAL PROGRAMMER CIRCUIT - PARTS LIST	30

FEATURE CHART

FEATURES	
Microwave	6
Grill	3
Combination	3x3
Weight Defrost	3
Weight Combination	3
Stage Cooking	3 stage
Delay Stand	Yes
Clock	12 Hrs
Word Prompt	English

1. CONTROL PANELS

- (1) Display Window
- (2) Time Pads
- (3) Auto Weight Combination Programs
- (4) Auto Weight Defrost Programs
- (5) Microwave Power Settings
- (6) Grill Settings
- (7) Combination Pad
- (8) Delay/Stand Pad:
This can be used to delay a cooking program for up to 9 hrs 99 mins., or used to time or for standing (non-cooking) time.
- (9) Clock Pad:
Press the clock pad. Using the minute and second pads set the clock (12 hr clock). Press clock pad again to stop colons flashing.
- (10) lb/oz Conversion Pad
- (11) Weight Selection Pads
- (12) Stop/Cancel Button:
Before Cooking:
One press clears your instructions.
During Cooking:
One press temporarily stops the cooking program. Another press cancels all your instructions and the time of day will appear in the display.
- (13) Start Button:
Press to start operating the oven. If during cooking the door is opened or Stop/Cancel Button is pressed once. Start Button has to be pressed again to continue cooking.



Beep Sound

A beep sounds when a button is pressed. If this beep does not sound, the setting is incorrect. When the oven changes from one function to another, two beeps sound. After completion of cooking, five beeps sound.

2. OPERATION AND DIGITAL PROGRAMMER CIRCUIT TEST PROCEDURE

Operation guide on the display.

To assist in programming, the next operation will appear on the display. When you are used to operating the oven, you can turn the operating guide off.

To turn off:

Press 3 times



OPERATING GUIDE OFF

To turn on:

Press 3 times



OPERATING GUIDE ON

1. SET CLOCK

OPERATION	DISPLAY
1. Plug the power supply cord into the wall outlet	WELCOME TO PANASONIC. REFER TO OPERATING INSTRUCTIONS
2. Press clock pad	SET TIME
3. Enter time of day Once — — Once Twice — — 5 Times	11 * 25 — — PRESS CLOCK
4. Press clock	11:25

2. MICROWAVE COOKING - 2 STAGE

OPERATION	DISPLAY
1. Place water load in oven	
2. Press Micro Power once to set High Power 	HIGH SET TIME
3. Set time at 5 sec by pressing 1 sec pad 5 times — 5 Times — 5 Times	5 SEC — — PRESS START HIGH
4. Press Micro Power pad 3 times to set Medium Power 	MEDIUM SET TIME
5. Set for 1 minute by pressing 1min pad once — Once 	1 MIN 00 SEC — — PRESS START MEDIUM

OPERATION	DISPLAY
6. Press start pad 	5 SEC
7. When 1st stage cooking has elapsed oven automatically switches to 2nd stage 	1 MIN 00 SEC
8. When 2nd stage cooking has elapsed oven beeps 5 times and shuts off	ENJOY YOUR MEAL

3. AUTO WEIGHT DEFROST

OPERATION	DISPLAY
1. Select desired program 	MEAT ITEMS SET WEIGHT **
2. Press g or lb and oz 	LB OZ MEAT ITEMS SET WEIGHT **
3. Enter the weight by pressing up and down pads 	1LB OZ PRESS START **
4. Press start pad 	9 MIN 08 SEC **

4. DELAY STAND

OPERATION	DISPLAY
1. Set power level and time	
2. Press stand 	STAND SET TIME
3. Set standing time 	H 1 00 PRESS START
4. Press start 	 1 MIN 00 SEC 1 MIN 00 SEC

5. DELAY START

OPERATION	DISPLAY
1. Press delay 	DELAY START SET TIME
2. Set delay time 	H 1 00 CHOOSE COOKING MODE
3. Set power level and time	
4. Press start pad 	1H 00


6. GRILL OPERATION

OPERATION	DISPLAY
1. Select grill power press once for grill 1 	GRILL 1 SET TIME 
2. Set cooking time 	1 MIN 00 SEC  GRILL 1 PRESS START
3. Press start 	 1 MIN 00 SEC

7. COMBINATION COOKING

OPERATION	DISPLAY
1. Press combination 	COMBINATION SELECT GRILL LEVEL 
2. Press stand 	GRILL 1   SELECT MICROPOWER
3. Select micropower low 	LOW   SET TIME
4. Set cooking time 	1 MIN 00 SEC   PRESS START
5. Press start 	 1 MIN 00 SEC 

8. AUTOWEIGHT COOK PROGRAM

OPERATION	DISPLAY
1. Select auto weight program 	CHILLED PIZZA   SET WEIGHT
2. Press to select grams or pounds and ounces 	LB OZ   CHILLED PIZZA SET WEIGHT
3. Enter the weight 	1LB OZ   PRESS START
4. Press start 	 9 MIN 17 SEC 

9. TO SET CHILD SAFETY LOCK

OPERATION	DISPLAY
1. Press start 3 times to display lock 	<i>* LOCK</i>

10. TO RESET CHILD LOCK

OPERATION	DISPLAY
1. Press stop/cancel 3 times Time of day or colon appears in display 	<i>11:25</i>

11. DEMONSTRATION MODE



OPERATION	DISPLAY
1. Press clock pad 3 times 	<i>DEMONSTRATION MODE PRESS ANY KEY</i>

12. CANCEL DEMONSTRATION MODE

OPERATION	DISPLAY
1. Press clock pad 3 times 	<i>11:25</i>



*Colours shown by () indicate colours of leadwire connector housing.



SYMBOL	COLOUR
OR	ORANGE
BL	BLUE
BR	BROWN
W	WHITE
Y	YELLOW
R	RED
GY	GREY
B	BLACK

4. DESCRIPTION OF OPERATING SEQUENCE

4.1 Variable power cooking control

HIGH VOLTAGE INVERTER POWER SUPPLY (U) controls output power by a signal from Digital Programmer Circuit (DPC). Power relay 1 stays on to supply power to the inverter circuit. The outpower is controlled by the drive signal level from the inverter circuit.

NOTE 1: The ON/OFF time ratio does not correspond with the percentage of microwave power since approximately 2 seconds are required for heating of magnetron filament.

NOTE 2: If microwave cooking is over 8 minutes with HIGH power, fan motor rotates for 1 minute after cooking to cool oven and electric components.

4.2 Grill cooking

The digital programmer circuit operates power relay 4 in the sequence as shown in the table

4.3 Combination cooking

Combination cooking is accomplished by microwave and grill cooking. The digital programmer circuit controls ON-OFF time of power relay 4 and the inverter control signal level, as shown in the table.

NOTE: After grill and combination cooking, fan motor rotates for 1 minute to cool oven and electric components.

4.4 Autoweight defrost, autoweight cook

When those auto control feature is selected and Start pad is pressed:

1. The digital programmer circuit determines the power level and cooking time to complete cooking and indicates the operating state in the display. The table shows the corresponding cooking times for respective weight by categories.
2. When cooking time in the display window has elapsed, the oven turns off automatically by the controlled signal from the digital programmer circuit.

NOTE: After one touch menu and auto reheat cooking, fan motor rotates for 1 minute to cool oven and electric components.

VARIABLE POWER COOKING

POWER SETTING	OUTPUT POWER APPROX.	RY-1	INVERTER CONTROL SIGNAL
HIGH	900W	stay ON	stay ON
DEFROST	270W	stay ON	ON/OFF
MEDIUM	600W	stay ON	stay ON
LOW	440W	stay ON	stay ON
SIMMER	250W	stay ON	ON/OFF
WARM	100W	stay ON	ON/OFF

GRILL COOKING

GRILL NO.	HEATER (RY-4)	
	ON (SEC)	OFF (SEC)
1	33	0
2	28	5
3	21	12

COMBINATION COOKING

COMBINATION NO.	HEATER (RY-4)		MICROPOWER LEVEL		
	ON (SEC)	OFF (SEC)	LOW	SIMMER	WARM
1	33	0	0	0	0
2	28	5	0	0	0
3	21	12	0	0	0

AUTOWEIGHT DEFROST

CATEGORY	WEIGHT	COOKING TIME
BREAD	100g	50 seconds
MEAT ITEMS	150g	2 mins 21 Secs
MEAT JOINTS	400g	7 mins

AUTOWEIGHT COOK

CATEGORY	WEIGHT	COOKING TIME
CHILLED PIZZA	200g	6 mins 10 secs
JACKET POTATO	150g	8 mins 52 secs
FROZEN POTATO PRODUCTS	100g	4 mins 30 secs

5. CAUTIONS TO BE OBSERVED WHEN TROUBLESHOOTING

Unlike many other appliances, the microwave oven is high-voltage, high-current equipment. Though it is free from danger in ordinary use, extreme care should be taken during repair.

CAUTION

Servicemen should remove their watches whenever working close to or replacing the magnetron.

5.1 Check the grounding

Do not operate on a 2-wire extension cord. The microwave oven is designed to be used when grounded. It is imperative, therefore, to make sure it is grounded properly before beginning repair work.


5.2 Inverter Warnings **NEW H.V.**

DANGER OF HIGH VOLTAGE AND HIGH TEMPERATURE (HOT/LINE) OF THE INVERTER POWER SUPPLY (U)

This High Voltage Inverter Power Supply circuit handles very high voltage and very high current for the magnetron tube. Though it is free from danger in ordinary use, extreme care should be taken during repair. As you can see, it looks like a TV flyback transformer, however the current is extremely large and so danger exists by its high current and high voltages.


The aluminium heat sink is also energized with high voltage (HOT), so do not touch when AC input terminal is connected to the power devices (Collector) is directly connected to the Aluminium heat sink.

The Aluminium heat sink may be HOT by heat energy; therefore, extreme care should be taken during servicing and replacing.



WARNING OF INVERTER POWER SUPPLY(U) GROUNDING


Check the High Voltage Inverter Power Supply circuit grounding. This High Voltage Inverter Power Supply circuit board must have a proper chassis ground by the grounding bracket to the chassis ground; otherwise, this H.V. Inverter circuit board will expose very high voltage and cause extreme DANGER! Be sure to have proper grounding by the grounding plate and screws.



WARNING OF DISCHARGING HIGH VOLTAGE CAPACITORS

Warning about the electric charge in the high voltage capacitors. For about 30 seconds after the oven is turned off, an electric charge remains in the high voltage capacitors in the inverter power supply circuit board.

When replacing or checking parts, remove the power plug from the outlet and short the Inverter output terminal of the magnetron filament terminals to the chassis ground with an insulated handle screwdriver to discharge. Please make sure to touch chassis ground side first then short to the output terminals.



WARNING

There is high-voltage present, with high-current capabilities in the circuits of the primary, and secondary windings, choke coil and heat sink of the Inverter. It is extremely dangerous to work on or near these circuits with oven energized. DO NOT measure the voltage in the high voltage circuit including filament voltage of magnetron.

WARNING

Never touch any circuit wiring with your hand nor with an insulated tool during operation.

5.3 When parts must be replaced, remove the power plug from the outlet.

5.4 When the 10A fuse is blown due to the operation of short switch:

WARNING

When the 10A 250V. fuse is blown due to the operation of short switch, you must replace Primary latch switch and short switch. Also replace power relay 1 (RY1) when the continuity check reads shorted contacts (1-2).

1. This is mandatory. Refer to "Adjustments and Measurement" for these switches.
2. When replacing the fuse, confirm that it has the appropriate rating for these models.
3. When replacing faulty switches, be sure mounting tabs are not bent, broken or otherwise deficient in their ability to hold the switches.

5.5 Avoid inserting nails, wire, etc. through any holes in the unit during operation.

Never insert a wire, nail or any other metal object through the lamp holes on the cavity or any other holes or gaps, because such objects may work as an antenna and cause microwave leakage.

5.6 Confirm after repair

1. After repair or replacement of parts, make sure that the screws of the oven, etc. are neither loose nor missing. Microwaves might leak if screws are not properly tightened.
2. Make sure that all electrical connections are tight before inserting the plug into the wall outlet.
3. Check for microwave energy leakage. (Refer to procedure for measuring microwave energy leakage).

CAUTION

MICROWAVE RADIATION

DO NOT BECOME EXPOSED TO RADIATION FROM THE MICROWAVE GENERATOR OR OTHER PARTS CONDUCTING MICROWAVE ENERGY.

IMPORTANT NOTICE **NEW H.V.**

1. The following components have potentials above 250V while the appliance is operated.

- Magnetron
- High voltage transformer (Located on Inverter(U))
- High voltage diodes (Located on Inverter(U))
- High voltage capacitors (Located on Inverter(U))

Pay special attention on these areas.

When the appliance is operated with the door hinges or magnetron is fixed incorrectly, the microwave leakage can reach more than $5\text{mW}/\text{cm}^3$. After repair or exchange, it is very important to check if the magnetron and the door hinges are correctly fixed.

5.7 Sharp edges

CAUTION

Please use caution when unpacking, installing or moving the unit, as some exposed edges may be sharp to touch and may cause injury if not handled with care.

6. DISASSEMBLY AND PARTS REPLACEMENT PROCEDURE

6.1 Magnetron

1. Discharge the high voltage capacitors.
2. Disconnect wire terminals to the thermal cutout.
3. Remove 1 screw holding the thermal cutout bracket to the magnetron.
4. Remove 1 screw holding the air guide A.
5. Remove 2 screws holding the tie bar.
6. Remove the oven lamp and lead wire harness cables from the Air guide A.
7. Remove the Air Guide A
8. Disconnect the 2 high voltage lead wires from the magnetron.
9. Remove 4 screws holding the magnetron.


NOTE: After replacement of the magnetron, tighten mounting screws properly making sure there is no gap between the waveguide and the magnetron to prevent microwave leakage.

CAUTION

When replacing the magnetron, be sure the antenna gasket is in place.

NOTE

Magnetron used for this model is unique type for inverter power supply system. Make sure to use the one as listed in the part list.





6.2 Inverter Power Supply(U) NEW H.V.

1. Discharge the high voltage capacitors.
2. Unplug 3 lead wire connectors from the Inverter Power Supply board.
3. Remove 1 screw to release the inverter grounding bracket.
4. Remove 1 screw and remove the inverter PCB plus support base from the oven.
5. Remove 1 screw to disconnect earth wire to magnetron.
6. Remove 4 screws holding inverter power supply board to the Inverter bracket.
7. Replace with replacement PCB and follow the steps in reverse.

CAUTIONS WHILE REPLACING INVERTER POWER SUPPLY(U)

1. Make sure to leave grounding plate in its place.
2. Make sure to securely tighten grounding screw through the side of chassis (base).
3. Securely connect 3 lead wire connectors.
4. Make sure the heat sink has enough space (gap) from the oven. Take special care not to touch any lead wire to the aluminium heat sink because it is hot.



6.3 Digital Programmer Circuit (DPC) and membrane key board.

NOTE: Be sure to ground any static electric charge built up on your body before handling the DPC.


1. Disconnect all connectors from D.P.C.
2. Remove 2 screws holding escutcheon base and slide the escutcheon base upward slightly.
3. Remove 1 screw holding earth wire to the chassis.
4. Release flat cable.
5. Remove 6 screws holding DPC DU.
6. Remove door lever.
7. Remove 6 screws holding DPC AU.

To replace membrane key board

8. Remove escutcheon bracket from escutcheon base by freeing 4 catch hooks on the escutcheon base.
9. Remove display window.
10. Remove membrane assembly by pushing away from base.

NOTE: 1. The membrane key board is attached to the escutcheon base with double faced adhesive tape. Therefore, applying hot air such as using a hair dryer is recommended for smoother removal.

2. When installing new membrane key board, make sure that the surface of escutcheon base is cleaned sufficiently so that any problems (shorted contacts or uneven surface) can be avoided.



6.4 Low voltage transformer and/or power relays (RY1)

NOTE: Be sure to ground any static electric charge built up on your body before handling the DPC.


1. Using solder wick or a desoldering tool and 30W soldering iron, carefully remove all solder from the terminal pins of the low voltage transformer and/or power relays.

NOTE: Do not use a soldering iron or desoldering tool of more than 30 watts on DPC contacts.

2. With all the terminal pins cleaned and separated from DPC contacts, remove the defective transformer/power relays and install new transformer/power relays making sure all terminal pins are inserted completely. Resolder all terminal contacts carefully.


6.5 Fan Motor

1. Remove 2 screws and remove tie bar.
2. Disconnect 2 lead wires from fan motor terminals.
3. Disconnect all lead wires from noise filter.
4. Remove the noise filter.
5. Remove 4 screws holding fan motor and upper and lower orifice. Detach the orifice assembly with fan motor from oven assembly.
6. Remove fan blade from the fan motor shaft by pulling it straight out.



6.6 Temp sensor (thermal protector)

1. Replace the temperature sensor by replacing the leadwire harness B as a complete unit.
2. Disconnect screw holding temperature sensor to chassis.
3. Disconnect connector CN4 from DPC DU.
4. Disconnect terminal from SW4 (secondary latch switch).
5. Replace as a whole unit.





6.7 Door disassembly

1. Remove door C from door E by carefully pulling outward starting from upper right hand corner using a flat blade screwdriver.
2. Remove 4 screws holding door E to door A assembly to separate door E from door A.
3. Remove door key and door key spring.

After replacement of the defective component parts of the door, reassemble it and follow the instructions below for proper installation and adjustment so as to prevent an excessive microwave leakage.

1. When mounting the door to the oven, be sure to adjust the door parallel to the bottom line of the oven face plate by moving the upper hinge and lower hinge in the direction necessary for proper alignment.
2. Adjust so that the door has no play between the inner door surface and oven front surface. If the door assembly is not mounted properly, microwave power may leak from the clearance between the door and oven.
3. Perform the microwave leakage test.




6.8 Turntable motor

1. Remove the motor cover by breaking off at the 8 spots indicated by arrows. (See Figure)

NOTE: After breaking off the motor cover, make sure that cut-off portions are properly trimmed off or bend to inside so that no sharp edge will expose to outside.




2. Disconnect 2 lead wires connected to the turntable motor.
3. Remove the turntable motor by removing 2 screws.

NOTE: To reinstall the motor cover, use 4x6 screw.



6.9 Quartz heater

1. Disconnect lead wires from heater terminals.
2. Remove 1 screw holding heater supports.
3. Remove the heater.



7. COMPONENT TEST PROCEDURE

CAUTION **NEW H.V.**

1. High voltage is present at the high voltage terminal of the High Voltage Inverter(U) including aluminium heat sink during any cook cycle.
2. It is neither necessary nor advisable to attempt measurement of the high voltage.
3. Before touching any oven components, or wiring, always unplug the oven from its power source and discharge the high voltage capacitors.

7.1 Primary Latch Switch, Secondary (Secondary Latch Switch and Power Relay B) Interlocks.

1. Unplug the lead connectors to Power Relay B and verify continuity of the power relay B 1-2 terminals.
2. Unplug lead connectors to Primary Latch Switch and Secondary Latch Switch.
3. Test the continuity of switches at door opened and closed positions with ohm meter (low scale).

Normal continuity readings should be as follows.


	Door Opened	Door Closed
Primary Latch Switch	$\infty \Omega$ (open)	0 Ω (close)
Secondary Latch Switch	$\infty \Omega$ (open)	0 Ω (close)
Power Relay B	$\infty \Omega$ (open)	$\infty \Omega$ (close)

7.2 Short Switch & Monitor Circuit **NEW H.V.**

1. Unplug lead wires from H.V. Inverter primary terminals.
2. Connect test probes of ohm meter to the disconnected leads which were connected to H.V. Inverter.
3. Test the continuity of short switch with door opened and closed positions using lowest scale of the ohm meter.

Normal continuity readings should be as follows.

Door Opened	Door Closed
0 Ω	$\infty \Omega$



7.3 Magnetron

Continuity checks can only indicate an open filament or a shorted magnetron. To diagnose for an open filament or shorted magnetron.


1. Isolate magnetron from the circuit by disconnecting the leads
2. A continuity check across magnetron filament terminals should indicate one ohm or less.
3. A continuity check between each filament terminal and magnetron case should read open.

7.4 Push button key board

Check continuity between switch terminals, by tapping an appropriate pad on the key board. The contacts assignment of the respective pads on the key board is as shown in digital programmer circuit (schematic).

7.5 Inverter Power Supply (U)

DO NOT try to REPAIR this H.V. Inverter power supply(U). Replace as whole H.V. Inverter(U) Unit.



INVERTER POWER SUPPLY DIAGRAM

7.6 Inverter Power supply(U) **NEW H.V.**

WARNING

Do not attempt to make any measurements in the high voltage circuitry of the inverter or magnetron.

See Troubleshooting of inverter circuit and magnetron on Pages 19 and 20 to determine if the inverter power supply is functioning.

7.7 Temp sensor (Thermal protector)


A temp sensor is mounted on top of the oven cavity at the left side. Its purpose is to automatically shut off the oven in case the cavity overheats for any reason.

The thermal protector will shut the oven down when the temperature of the cavity reaches 257°F (125°C).

The device is connected to the DPC on touch control models. When the thermal protector exceeds its temperature it will turn off the power to oven cavity and display will go to reset mode. The cooking program can be reset after cool-down.

THERMISTOR RESISTANCE VALUE

30K-120K at 10°C-30°C (50°F-86°F)



02-042

8. MEASUREMENTS AND ADJUSTMENTS

WARNING

- For continued protection against radiation hazard, replace only with identical replacement parts.
- When the 10 Amp. fuse is blown due to the operation of short switch, you must replace Primary latch switch and short switch. Then follow the installation procedures below.
- Interlock switch replacement - In replacing faulty switches, be sure mounting tabs are not bent, broken or otherwise deficient in their ability to hold the switches.
- Refer to schematic diagram to ensure proper connection.

8.1 Installation of Primary latch switch, Secondary latch switch and Short switch.

1. When mounting Primary latch switch, Secondary latch switch and short switch to door hook assembly, mount the Primary latch switch, the Secondary latch switch and the short switch to the door hook assembly as shown in the illustration.

NOTE: No specific adjustment during installation of Primary latch switch, Secondary latch switch and short switch to the door hook is necessary.

2. When mounting the door hook assembly to the oven assembly, adjust the door hook assembly by moving it in the direction of arrow in the illustration so that the oven door will not have any play in it. Check for play in the door by pulling the door assembly. Make sure that the latch keys move smoothly after adjustment is completed. Completely tighten the screws holding the door hook assembly to the oven assembly.
3. Reconnect the short switch, primary & secondary latch switches and check the continuity of the monitor circuit and all latch switches again by following the components test procedures.

8.2 Measurement of microwave output

The output power of the magnetron can be determined by performing IEC standard test procedures. However, due to the complexity of IEC test procedures, it is recommended to test the magnetron using the simple method outlined below.

Necessary Equipment:


*1 litre beaker

*Glass thermometer

*Wrist watch or stopwatch.

NOTE: Check the line voltage under load. Low voltage will lower the magnetron output. Take the temperature readings and heating time as accurate as possible.

1. Fill the beaker with exactly one litre of tap water. Stir the water using the thermometer and record the beaker's temperature (recorded as T1).
2. Place the beaker on the center of glass cook plate.
3. Set to high power and heat for exactly one minute.
4. Stir the water again and read the temperature of the beaker (recorded as T2).
5. The normal temperature rise at High power position for each model is as shown in table.



Please confirm that the gap between the switch housing and switch actuator levers is no more than 0.7 mm when the door is closed.

01-033

TABLE (1 ℓ - 1min. test)

RATED OUTPUT	TEMPERATURE RISE
900W (IEC705-88)	(7°C)

9. TROUBLESHOOTING GUIDE NEW H.V.

CAUTION

1. **DO NOT try to REPAIR this H.V. Inverter power supply(U). Replace as whole H.V. Inverter(U) Unit.** When returning H.V. Inverter(U) make sure to pack as originally packed.
2. **DO NOT RE-ADJUST PRESET VOLUME on the H.V. Inverter(U).** It is very dangerous to repair or adjust without sufficient test equipment because this circuit handles very large current with very high voltage.
3. Ensure proper grounding before checking for trouble.
4. Be careful of the high voltage circuitry, taking necessary precautions when troubleshooting.
5. Discharge the high voltage that remains in the Inverter(U).
6. When checking the continuity of the switches or the H.V. Inverter, disconnect one lead wire from these parts and then check continuity with the AC plug removed. To do otherwise may result in a false reading or damage to your meter. When disconnecting a plastic connector from a terminal, you must hold the plastic connector instead of the lead wire and then disconnect it, otherwise lead wire may be open or the connector cannot be removed.
7. Do not touch any parts of the circuitry on the digital programmer circuit, since static electric discharge may damage this control panel.
Ensure you are touching the ground while working on this panel to discharge any static charge in your body.
8. 240VAC is present on the digital programmer circuit (Terminals of power relay's and primary circuit of low voltage transformer). When troubleshooting, be cautious of possible electrical shock hazard.

Before troubleshooting, operate the microwave oven following the correct operating procedures in the instruction manual in order to find the exact cause of any trouble, since operator error may be mistaken for the oven's malfunction.

	SYMPTOMS	CAUSE	CORRECTIONS
1.	Oven is dead. Fuse is OK. No display and no operation at all.	1. Open or loose lead wire harness. 2. Open thermal cutout (Magnetron) 3. Open low voltage transformer 4. Defective DPC AU or DPC DU	Check fan motor when thermal cutout is defective.
2.	No display and no operation at all. Fuse is blown.	1. Shorted lead wire harness 2. Defective primary latch switch (NOTE 1) 3. Defective short switch (NOTE 1) 4. Defective Inverter power supply (U) NEW H.V. Refer to component test procedure (Page 15)	Check adjustment of primary, secondary latch switch and short switch including door.
		NOTE 1: All of these switches must be replaced at the same time. (Refer to adjustment instructions.) Check continuity of power relay B's contacts (between 1 and 2) and if it has continuity, replace power relay B also.	
3.	Oven does not accept key input (Program).	1. Key input is not in sequence. 2. Shorted push button on DPC AU. 3. Defective DPC AU.	Refer to operation procedure. Refer to DPC troubleshooting.
4.	Oven lamp and turntable motor turn on when oven is plugged in with door closed	1. Misadjustment or loose wiring of secondary latch switch. 2. Defective secondary latch switch	Adjust door and latch switches.
5.	Timer starts countdown but no microwave oscillation. (No heat while oven lamp and fan motor turn on)	1. Off-alignment of latch switches 2. Open or loose connection of high voltage circuit especially magnetron filament circuit NOTE: Large contact resistance will bring lower magnetron filament voltage and cause magnetron to have lower output and/or be intermittent. 3. Defective high voltage component H.V. Inverter NEW H.V. Magnetron 4. Open or loose wiring of power relay B 5. Defective primary latch switch. 6. Defective power relay B or DPC AU or DU.	Adjust door and latch switches. Check high voltage component according to component test procedure (Page 15) and replace if it is defective. Refer to DPC troubleshooting.
6	Microwave output is low. Oven takes longer time to cook food.	1. Decrease in power source voltage 2. Open or loose wiring of magnetron filament circuit. (Intermittent oscillation) 3. Aging change of magnetron.	Consult electrician Refer to output test procedures by water temperature raising test.
7	Turntable on when door is opened.	1. Shorted primary latch switch.	
8	Oven does not operate and returns to plugged in mode as soon as start pad is pressed.	1. Opened or loose wiring of temp sensor 2. Defective temp sensor	Check tighten screws on escutcheon base bracket, D.P.C board and temp sensor.

	SYMPTOMS	CAUSE	CORRECTIONS
9	Loud buzzing noise can be heard.	1. Loose fan and fan motor	
10	Turntable motor does not rotate.	1. Open or loose wiring of turntable motor 2. Defective turntable motor	
11	Oven stops operation during cooking.	1. Open or loose wiring of primary and secondary latch switch 2. Operation of thermal cutout (Magnetron)	Adjust door and latch switches.

Troubleshooting of Inverter Circuit (U) and Magnetron **NEW H.V.**

Oven shuts down after approximately 15 or 33 seconds.

If the microwave oven shuts down after a short time in micropower mode, conduct the following test.


The microwave oven must be set in test mode to activate the self diagnostic failure code system.

SELF TEST MODE



When oven is set in test mode place water load in oven, set micropower to high and time to 1 minute, press start.

H97, H98 appears in display window a short time after start key is pressed and there is no microwave oscillation.



NOTE: DO NOT try to REPAIR this Inverter Power Supply(U) and also DO NOT RE-ADJUST PRESET VOLUME on the board. It is very dangerous to repair or adjust without sufficient test equipment because this circuit handles very high voltage and very large current. Off alignment of inverter board operation is dangerous. Operating a misaligned Inverter circuit is dangerous due to the very high voltage and current that is produced by this board. Defective boards must be replaced with a new one.

*Check magnetron filament for open or short to casing before proceeding to determine a good magnetron.

Alternative way to troubleshooting oven with AC Ampare meter used. **NEW H.V.**

Oven shuts down after approximately 15 or 33 seconds.

If the microwave oven shuts down after a short time in micropower mode, conduct the following test.


The microwave oven must be set in test mode to activate the self diagnostic failure code system.

SELF TEST MODE



When oven is set in test mode place water load in oven, set micropower to high and time to 1 minute, press start.

H97, H98 appears in display window a short time after start key is pressed and no microwave oscillation with AC Ampare meter used for troubleshooting.



NOTE: DO NOT try to REPAIR this Inverter Power Supply(U) and also DO NOT RE-ADJUST PRESET VOLUME on the board. It is very dangerous to repair or adjust without sufficient test equipment because this circuit handles very high voltage and very large current. Off alignment of inverter board operation is dangerous. Operating a misaligned Inverter circuit is dangerous due to the very high voltage and current that is produced by this board. Defective boards must be replaced with a new one.

*Check magnetron filament for open or short to casing before proceeding to determine a good magnetron.

Trouble Related to Digital Programmer Circuit

SYMPTOM	STEP	CHECK	RESULT	CAUSE/CORRECTIONS
No display when oven is first plugged in. Oven is dead.	1	Fuse pattern of DPC	Normal	STEP 2
			Open (NOTE)	Shorted Circuit of ZNR, L.V.T., Oven Lamp etc. Replace DPC
	2	IC10 Pin 9 (12V line)	Abnormal 0V	IC10
			Normal 12V	→ Step 3
	3	IC-1 Pin 16 voltage (Emitter of Q10)	Abnormal	ZD10, Q10, Ribbon Cable
			Normal = 5V	→ Step 4
	4	IC-1 pin 10 voltage (15 pin of IC220)	Abnormal	IC-220
			Normal	→ IC-1, CX1

NOTE

Procedure of fuse pattern repairing is as follows:

1. When the fuse pattern (PF2) opens.

(1) Remove the jumper wire (PF3).

(2) Insert the removed jumper wire (PF3) to "PF2" position and solder it. If both "PF2" and "PF3" fuse patterns are open, please replace DPC.


NOTE: * At the time of these repairs, make visual inspection of the varistor for burning damage and examine the transformer with tester for the presence of layer short-circuit (check primary coil resistance).

If any abnormal condition is detected, replace the defective parts.



SYMPTOM	STEP	CHECK	RESULT	CAUSE/CORRECTIONS
No key input	1	Push button switch	Abnormal	Push button switch
			Normal	IC-1
No beep sound	1	IC-1 pin 8, voltage	Abnormal	IC-1
			Normal	IC220, BZ310
Power relay A(RY-2) does not turn on even though the program has been set and the start pad is tapped.	1	IC-1 pin 11 voltage while operation	Abnormal	IC-1
			Normal = 5V	→ Step 2
	2	Short circuit between pin 6 and pin 16 of IC-2	Still not turn on	RY-2
			RY-2 turns on	IC-220
No microwave oscillation at any power setting.	1	IC-1 pin 7 and 72 voltages while operation at high power	Abnormal	IC-1
			Normal 7---5V, 72---5V	→ Step 2
	2	Q220 transistor	Abnormal	Q220
			Normal	IC220
Dark or unclear display	1	Replace display and check operation	Normal	DISPLAY
			Abnormal	IC-1
Missing or lighting of unnecessary segment	1	Replace IC-1 and check operation	Normal	IC-1
			Abnormal	DISPLAY
Oven shuts down on Micropower after a short time (set in test mode) (set high power 1 Min) H97/H98 appears in window and oven stops operation. Program High power for 1 minute and conduct following test quickly, unless H97/H98 appears and oven stops. NEW H.V.	1	Unplug CN702(2 pin) connector and measure voltage between terminals	0V	1. Latch switch 2. DPC/Power relay
			AC line voltage of 240V	→ Step 2
	2	Unplug CN701(3 pin) connector and measure pin 1 voltage	0V	1. DPC
			Approx. AV 3V	1. Magnetron 2. Inverter

How to Check the Semiconductors Using an OHM Meter

Diode




Transistor



Digital Transistor

PNP Transistor




	FORWARD	REVERSE
A-K	SMALL	∞

	FORWARD	REVERSE
B-E	SMALL	∞
B-C	SMALL	∞
C-E	∞	∞

	FORWARD	REVERSE
E-B	SMALL	∞
C-B	SMALL	∞
C-E	∞	∞

	FORWARD	REVERSE
E-B	10kΩ~30kΩ	10kΩ~30kΩ
C-B	50kΩ~90kΩ	∞
C-E	40kΩ~80kΩ	∞

10. EXPLODED VIEW AND PARTS LIST



11. PARTS LISTS

NOTES: *When ordering replacement part(s), please use part number(s) shown in this parts list.


Do not use description of the part.

*Important safety notice:

Components identified by ! mark have special characteristics important for safety. When replacing any of these components, use only manufacturer's specified parts.

Ref. No		Part No.	Part Name and Description	Pcs/set	Remarks
1	!	E610U4L50GS	THERMAL CUTOFF ASSEMBLY	1	
2	!	E900C4L20BP	POWER CORD	1	
3		AEE9108A20GN	POWER CORD CLIP	1	
4	!	E030A4L50GS	LEADWIRE HARNESS	1	
5	!	E607X4L00BP	NOISE FILTER ASSEMBLY	1	
6	!	E67597550GP	10A FUSE	1	
7	!	E30208000BP	DOOR HOOK	1	
8	!	AEE6142-F61	PRIMARY LATCH SWITCH	1	V-15G-3C26
9	!	E61785180AP	SHORT SWITCH	1	L-2C2-2
10	!	E61425180AP	SECONDARY SWITCH	1	L-3C2-2
11	!	E31384830AP	HOOKE SPACER C	1	
12	!	E31374830AP	HOOKE SPACER B	1	
13		E41444L00GS	UPPER ORIFICE	1	
14	!	E400A4760JP	FAN MOTOR	1	
15		E42094L00GS	LOWER ORIFICE	1	
16		E4008-1640	FANBLADE	1	
17		E40314L00GS	AIR GUIDE C	1	
18	!	XTWANE4+12B	SCREWS	4	FOR MAGNETRON
19	!	2M236-M42E2	MAGNETRON	1	
20	!	E030E4L00GS	H.V.LEADWIRE	1	
21	!	E610T6700BP	OVEN LAMP	1	
22		E20994L00GS	TIE BAR	1	
23	!	E40254L00GS	AIR GUIDE A	1	
24	!	E66014L00GS	INVERTER EARTH BRACKET	1	
25	!	E65854L00GS	INVERTER SUPPORT BRACKET	1	
26	!	E606Y4L10GP	INVERTER	1	
27		E10014L00GS	BASE PLATE	1	
28		E10614L00GS	WATER SHEILD	1	
29		E1008-1180	RUBBER FOOT	4	
30		E110D4L00HBP	OUTER PANEL	1	
31	!	E63268960JP	TURNTABLE MOTOR	1	
32		AEE2177-F80	PULLEY SHAFT WASHER	1	
33		E21315540AP	PULLEY SHAFT	1	
34		E30074L00GS	LOWER HINGE	1	
35		E09020000UK	CUSHION	1	
36	!	E01507550BP	WARNING LABEL	1	
37	!	E20554L00GS	COVER A	1	
38	!	XT4+W5V	SCREW	1	H1 TORQUE FOR COVER A
39		E200A4L50GS	OVEN CAVITY	1	
40	!	E030F4L00GS	LEADWIRE HARNESS B	1	INC. THERMISTOR
41		E64924L50GS	LEFT HEATER BRACKET	1	
42		E03596540GP	GRILL LINK	1	
43		E22784L50GS	UPPER HEATER PANEL	1	
44		E630G7550GP	GRILL HEATER	1	
45		E40244N30BP	EXHAUST GUIDE	1	
46		E64604L50GS	RIGHT HEATER BRACKET	1	
47	!	E00064080BP	WARNING LABEL	1	
48		E11406520GP	STOPPER A	2	
49		E66224L50GS	OUTER PANEL SPACER	1	


12. DOOR ASSEMBLY



Ref. No.	Part No.	Part Name & Description	Pcs/Set	Remarks
D1	E302A4L20HBP	DOOR A SCREEN B ASSEMBLY	1	
D2	E30214000AP	DOOR KEY SPRING	1	
D3	E30184L00GS	DOOR KEY A	1	
D4	E302K4L00GS	DOOR E AND SCREEN A UNIT	1	
D5	E31454L00GS	SCREEN A	1	
D6	E30854L00GS	DOOR C	1	
D7	E30064L00GS	UPPER HINGE	1	

NOTE: When ordering any door component also order door C as this part may become damaged during disassembly.


13. ESCUTCHEON BASE ASSEMBLY



Ref. No.		Part No.	Part Name & Description	Pcs/Set	Remarks
E1		E80724L10HBP	DOOR OPENING BUTTON	1	
E2		E80378AOAG	DOOR BUTTON SPRING	1	
E3		E80344L10HBP	ESCUTCHEON BASE	1	
E4		E81274L10BP	ESCUTCHEON BACK PLATE	1	
E5	!	E603L4L20BP	DPC AU	1	
E6		E66164L00GS	RIBBON CABLE	1	
E7		E82564L10BP	DOOR OPENING LEVER	1	
E8	!	E603Y4L20BP	DPC DU	1	
E9		E83264L10BP	DISPLAY SHEET	1	
E10		E00074L20BP	NAME PLATE	1	
E11		E83374L20HBP	ESCUTCHEON SHEET	1	

NOTE 3: Please order Escutcheon Base and Name Plate together.

14. PACKING AND ACCESSORIES




Ref. No.	Part No.	Part Name & Description	Pcs/Set	Remarks
P1	E060V4L20BP	WIRE RACK ASSEMBLY	1	
P2	E06435870GS	WIRE RACK FOOT	3	
P3	E290D6150WN	ROLLER RING	1	
P4	E06014L00BP	GLASS TRAY	1	
P5	E00034L20BP	INSTRUCTION BOOK	1	
P6	E01695750BP	SERVICE CENTER LIST	1	
P7	E01084L00GS	TRAY PACKING	1	
P8	E01054L00BP	LOWER FILLER	1	
P9	E01024L20HBP	CARTON BOX	1	
P10	E01074L00GS	DOOR SHEET	1	
P11	AEE01066Q0BP	VINYL COVER	1	
P12	E01044L00BP	UPPER FILLER	1	

E607X4L00BP - Noise Filter Assembly

Ref. No.	Part No.	Description	Qty	Remarks
R1	ERG1SJ753P	RESISTOR	1	75K Ω 1W
C1&C2	AECQJ5225KX1	CAPACITOR	2	2.2 μ f
C3&C4	ECKMNA472ME	CAPACITOR	2	4700pF 250V AC
L1	E621A4J00XN	FILTER COIL	1	2.4mH
GND	E03594080BP	EARTH WIRE	1	
F1	E62316010BP	FUSE HOLDER	1	10A 250V AC

15. DIGITAL PROGRAMMER CIRCUIT



16. DIGITAL PROGRAMMER CIRCUIT - PARTS LIST

DPC AU - E603L4L20BP

Ref. No.	Part No.	Description	Qty	Remarks
CN6	AEEM19FESVKN	19PIN CONNECTOR	1	
DISP110	AEDDHLC4L2BP	LCD	1	
IC220	AN6747B	CUSTOM IC	1	
D180-D182	AESQTLGE260T	GREEN LED	3	
CX320	EF0MC8004T4	CERAMIC RESONATOR	1	
SW40-42	EVQ11L05R	PUSH SWITCH	20	
SW44-48				
SW51				
SW53-63				
R182	ERDS2TJ361T	RESISTOR	1	360Ω
R314	ERDS2TJ181T	RESISTOR	1	180Ω
C22	AECF50F104Z	CAPACITOR	1	100 nF
D40-41	AESS1N4148M	DIODE	2	
IC1	AEIC8C34A119	IC1	1	
"C21,C40-C48"	AECU1F103Z50	CHIP CAPACITOR	12	10 nF
"C110,C460"				
"C20,C220-C222"	AECU1F104Z25	CHIP CAPACITOR	5	100nF
C224				
"R20,R111-R113"	ERJ3GSYJ102V	CHIP RESISTOR	5	1KΩ
R461				
R340-R343	ERJ3GSYJ103V	CHIP RESISTOR	4	10KΩ
R650	ERJ3GSY104V	CHIP RESISTOR	1	100KΩ
R110	ERJ3GSYJ220V	CHIP RESISTOR	1	22Ω
R460	ERJ3GSYJ333V	CHIP RESISTOR	1	33KΩ
R330	ERJ3GSYJ471V	CHIP RESISTOR	1	470Ω
R40-R48	ERJ3GSYJ683V	CHIP RESISTOR	9	68KΩ

DPC DU - E603Y4L20BP

Ref. No.	Part No.	Description	Qty	Remarks
CN5	AEEM19FEBVKN	19 PIN CONNECTOR	1	
CN1	AEEMMD05507W	7 PIN CONNECTOR	1	
"RY1,RY4"	AEGG5G1A12	RELAY	2	12V
"RY2,RY3"	AEBGG5N1A12	RELAY	2	12V
D1	ERZV10D511CS	VARISTOR	1	
"D2,D3"	ERZV10D112C1	VARISTOR	2	
1C25	AEICP25011HL	PHOTOCOUPLER	1	
D26	AESTS1WBA60B	DIODE BRIDGE	1	
BZ310	EFBAH20C001	BUZZER	1	2KHz
IC10	ETXMJ197X1BG	SWITCH POWER SUPPLY	1	
CN3	AEEMMF00703B	3 PIN CONNECTOR	1	
CN4	AEEMMF00D04W	4 PIN CONNECTOR	1	
L10	EXCELDJR35V	INDUCTOR	1	
"Q220,Q221"	AESCKTC200	NPN TRANSISTOR	1	
C11	ECEA1CKA220B	CAPACITOR	1	22μF 16V
C25	ECA2WHG100E	CAPACITOR	1	10μF 450V
C10	EEUFC1C471B	CAPACITOR	1	470μF 16V
R27	ERX12SJ1R0E	RESISTOR	1	1Ω 1/4W
Q10	2SD1859TV2	POWER TRANSISTOR	1	
"R220,R22"	ERDS2TJ103T	RESISTOR	4	10KΩ 10%
R24				
C330	ECBT1E103ZF5	CAPACITOR	1	10nF
C331	ECBT2H681KB5	CAPACITOR	1	68pF
R11	ERDS2TJ104T	RESISTOR	1	100KΩ 5%
"R221,R223,R310"	ERDS2TJ102T	RESISTOR	3	1KΩ 5%
R10	ERDS2TJ821T	RESISTOR	1	820Ω
D220-D225	AESS1N4148M	DIODE	6	
D25	AEDNERA1502	DIODE	1	
ZD10	AEDZ5R6ES2T1	ZENER DIODE	1	
"R26,R25"	ERDS1FJ563T	RESISTOR	2	56KΩ 1/2W

NOTES:

NOTES:



S - 4L20BP
Printed in the UK